

Pre-Takeoff Power on Ops Test

1. Open up laptop
2. Press Power On Button
3. Observe WIN XP start up screen (This takes about 2 minutes)
4. Observe normal desktop screen
5. Observe "SDIS STATUS" open window which states:
6. "You must be connected to the internet in order for the configuration to be verified. Make sure that the satellite phone is dialed in before proceeding"
7. Click "OK"
8. Observe "SDIS STATUS" open window which states: "Error pulling missions from WMIRS"
9. Click "OK"
10. Observe "SDIS STATUS" open window that states: "There are no open WMIRS Missions Available. Contact NOC at 1-888-211-1812"
11. Click "OK"
12. Observe open window which states: "USAF Auxiliary – SDIS STATUS monitor and configuration utility with mail client: "SETUP MISSION" button and "REFRESH WMIRS" button
13. Click the "GlobalStar" icon on the left side of the desktop and observe a text box that comes up that indicates "DIALING....." After a short time observe "GlobalStar now Connected"
14. Left Click – "Refresh WMIRS" button
15. Observe: "UPDATE SUCCESSFUL"
16. Left Click – "SETUP MISSION"
17. Observe mission dropdown box
18. HIGHLIGHT and SELECT - your current mission from this box
19. Click – "SET MISSION"
20. Observe "Mission Setup Properly"
21. Click – "OK"
22. Look on the lower right status bar
23. Fly arrow over the left hand double computer icon and LEFT CLICK
24. Observe: "Global Star Status" window open
25. Observe connection status: "CONNECTED" approx. 19.2 KBps
26. Click – DISCONNECT
27. Observe status bar
28. Observe double computer icon will vanish